

WINDMILL FIRE PIT | CLASSIC WEATHERED WALLSTONE

PROJECT SUMMARY



OVERALL DIMENSIONS:

44" wide x 44" deep x 16" high

MATERIAL REQUIRED:

48 Classic Weathered WallStones
26"x26" Square Steel Fire Pit Insert

BLOCK & CAP SIZE:

12-L x 8-W x 4-H in (approx.)
305-L x 203-W x 102-H mm



INSTALLATION GUIDELINES:

SUGGESTED TOOLS. Safety glasses, gloves, tape measure, level, rubber mallet, shovel, wheelbarrow, hand tamper (or plate compactor), and class 'A' gravel.

BASE PREPARATION. Dig an area that is 6" larger on all sides of your project and at least 8" deep. Compact class 'A' gravel in the area 2" at a time and fill to a depth of 6" to withstand weight of project.

NOTE: THE WINDMILL FIRE PIT IS SOLD AS A PACKAGE.

AVAILABLE COLOUR: NATURAL CHARCOAL



ROW 1	ROW 2	ROW 3	ROW 4
<p>BIRDS EYE VIEW 44"x44"</p>			
<p>Start installing your first row of blocks by placing your first stone on the compacted base.</p> <p>Make sure the block is level from side to side and front to back.</p> <p>Continue with your next block being sure to follow the above pattern for stone placement. Install additional stones so they are flush to each other with no gaps.</p> <p>All stones in the first row need to be leveled from side to side and front to back.</p>	<p>The second row of blocks should be staggered vertically from the row below.</p> <p>This will increase the stability of your project.</p> <p>The second row is installed in the same manner as the first – follow the second pattern above for stone placement.</p>	<p>Row 3 is installed by following the above pattern for stone placement.</p> <p>Ensure that blocks are staggered vertically from the row below.</p>	<p>Row 4 is installed by following the above pattern for stone placement. Ensure that blocks are staggered vertically from the row below.</p> <p>PLACEMENT OF FIRE PIT INSERT:</p> <p>The 26"x26" fire pit insert (represented by the dotted line above) is the last step to complete. With two people, one on each side, carefully lower and centre the insert inside your project. The lip on the insert should sit on top of the WallStone units.</p>

